

Storage Procedures:

Z1 – Thermal Inkjet (TIJ)

Controller Storage

Store the controller under the following conditions:

- Store indoors
- Keep dry and free of dust
- Do not expose to aggressive media (e.g. abrasives or caustic substances)
- Keep away from direct sunlight
- Avoid mechanical shock
- Storage temperature: 40 – 113° F (5° C to 45° C)
- Relative humidity: maximum 60% not condensing



Ink Cartridge Storage

To store ink cartridge:

Storage recommendations vary depending on how long the cartridges will be out of use:

- **UNDER 2 DAYS** – leave the ink cartridges in the print head holder. Wipe off, if necessary, before restart.
- **OVER 3 DAYS** – insert the ink cartridge in a cartridge clip (CartClip).


To do this:

- Remove ink cartridge from the controller
- Insert the ink cartridge in the CartClip. Pull the nose of the CartClip back slightly until the cartridge clicks into place



To resume using the ink cartridge:

- Pull the nose of the CartClip back slightly and remove the cartridge.
- If needed, clean the ink cartridge (see Z1 Instruction Manual p 86-87)
- Reinstall ink cartridge in controller unit



Contact Zanasi USA today!

T 763-593-1907 W zanasiusa.com E service@zanasiusa.com